

Transmitters and Receivers Under Table Mounting Instructions

The Terra transmitters and Receivers are rack mountable or under table mountable. The TXO / RXO Under Table Mount (166-112105-01) is used to secure Terra Transmitters (Terra TXO 102 SO) and Terra Receivers (RXO 101 SO) under tables or other surfaces parallel to the ground. The under table mount offers screw holes and open space to support efficient mounting to keep air vents open on the Terra units. Christie does not provide the screws or surface to attach the mounting hardware to a table or other surface.

To table mount a unit

1. Obtain screws (4-6) with corresponding washers that have a surface area greater than the openings in the mounting bracket and fit in the open slots (no greater than Metric, M4 or English, #6 diameter) in the mounting brackets.
2. Remove the four side screws on each side of the Terra unit. Discard the screws.
3. Align the under table mounting bracket to the side of the Terra unit and attach it using the provided screws. Repeat with the other bracket on the other side.
4. Tighten the screws to secure the brackets.
5. In the table, drill pilot holes for the screws that align with the openings in the mounting bracket. Supporting the bottom of the unit, secure the unit to the table by inserting the screws through the holes in the bracket into the predrilled holes in the table.

